

Strut Nut Tool Set 3pc

A set of 3 sockets for use on MacPherson struts designed for Volkswagen/Audi front and rear struts. Special top nut sockets which are designed to hold the damper shaft during removal and refitting.



Additional Information

- Suitable for: Volkswagen Polo, Golf, Passat & Audi 80.
- Sizes: 10.5, 12.5, 14.5mm.

-
-
-

<http://lasertools.co.uk/product/3466>



