

Front Body Panel Guide Set - VW T5

These pins are screwed in place of the front panel mounting bolts to allow the panel to be slid away from the engine without disconnecting all fluid pipes etc.



Additional Information

- Front body panel guide set.
- Application: Volkswagen Transporter T5 from 2004 onwards.
- Gives essential room without disconnecting fluid pipes etc.
- Equal to OEM T10228. Size M8 x 1.25 x 13mm x 200mm (4 supplied).
- Made in Sheffield

<http://lasertools.co.uk/product/6241>

