

Non Marring Imperial Socket/Wrench Insert Set 4pc

Non-marring inserts to fit Imperial (AF) socket and spanners inserts which help prevent damage to chrome or anodised fixings. Ideal for use on classic and show vehicles.



Additional Information

- Prevents damage to chrome and anodised bolts (non marking).
- Sizes: 3/8" to fit 1/2" socket, 7/16" to fit 9/16" socket, 1/2" to fit 5/8" socket and 9/16" to fit 11/16" socket.
- Can be used with sockets or ring spanners.
- Manufactured from PA6 nylon and glass fibre composite.
- Imperial (AF) sizes ideal for classic cars and motorcycles. For metric version, see Laser Part No. 7463.

<http://lasertools.co.uk/product/8468>

