

## TPMS 4 Way Valve Tool

This handy TPMS valve tool is designed for removing and replacing 11mm & 12mm TPMS sensor nuts and reseating the bevelled and non bevelled sensor grommets.



### Additional Information

- For removing and replacing TPMS sensor nuts when replacing tyres.
- 4 way tool.
- 11mm, 12mm.
- Also for seating bevel and non-bevelled sensor grommets.
- 

<http://lasertools.co.uk/product/5065>



