

## Lambda Sensor Remover/Installer 22mm

An essential two-piece tool designed to allow the use of an air hammer to loosen difficult or stuck 22mm Lambda sensors.



### Additional Information

- 200mm reach to give excellent air hammer access.
- 3/8" D head which allows the use of a torque wrench when tightening sensors.
- The perfect addition to Laser Air Hammers, Part Nos. 6031 and 6077.
- Use air hammer for extraction only; for fitting use 3/8" D tool.
- 

<http://lasertools.co.uk/product/6098>

Video available: <https://youtu.be/FVqBPT8cUeI>

