

Front Crankshaft Seal Extraction Tool - Iveco & FUSO

A crankshaft front oil seal extraction tool specifically designed for the Iveco Daily and Fiat Ducato 3.0L diesel engines. Designed to screw in to the old seal in accordance with OEM instructions to ensure the seal is removed properly and without damage to the casing.



Additional Information

- Applications include: Euro 5, Iveco Daily III, IV, V, VI (from 2002), Fiat Ducato, Peugeot Boxer (from 2006) & FUSO.
- Engine applications include: Iveco & Fiat 3.0L diesel engines.
- Designed to extract OEM seals.
- Use in accordance with OEM instructions. OEM equivalent 99340059, MH063989.
- For front crankshaft seal fitting see Laser Part No. 9214. For rear crankshaft oil seal replacement see Laser Part No. 8697.

<http://lasertools.co.uk/product/9215>

